

INSTALLATION GUIDE FOR MCK5030BN AND MCK5030MBK



SAFETY INFORMATION

Released Date: 2024-09-10

Please read and understand this entire manual before attempting to assemble, install or operate the product.

WARNING

- RISK OF ELECTRIC SHOCK Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE Use bulbs specified by the markings and/or labels on the fixture.

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED








CARE AND MAINTENANCE

- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.
- When the lamp is repaired, the glass lampshade or decorative part should be removed first.


If you need further assistance call Quoizel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com.

PACKAGE CONTENTS



MOUNTING HARDWARE

x 1











Wire Connector


Outlet Box Screw




















Your installation is now complete! Restore electricity and save this sheet for future reference.